




QUICK START GUIDE

Clinician Full Setup









PROTEOR QUATTRO™


Microprocessor Knee



- 1. Flexion angle limiter
- 2. Flexible back cover
- 3. Rear brace



- 4. Replaceable knee pad
- 5. Cylinder shaft
- 6. Dead battery resistance adjustment screw
- 7. Charging port and dust cover
- 8. Battery charger and cable



9. Pyramid adapter


10. Keypad

Button	Status	Charge level	LED description
Battery Status	Fully charged	51–100%	•
	Charged	21%-50%	((•))
	Low	11–20%	•
	Very low	1–10%	((•))
	Knee reboot	Hold 6 seconds	((•)) ((•))
Button	Function	Status	LED description
12 Change Mode	Check activity Press and release	Unlocked	Walking: (O) Alternate: (((O)))
		Locked	Error: ((((())) (((()))
	Enable/disable lock	Lock engaged	0
	Press twice	Locked engaged, with very low battery	((•))
		Locked disengaged	Previous LED activity resumes
	Toggle between walking and alternate	Current activity	Walking (O)
		Current activity	Alternate (((O)))

LED Key	
Solid green	•
Blinking green	((•))
Fast blinking green	
Solid red	•
Blinking red	((•))
Fast blinking red	
Blinking blue	((•))
Solid white	0
Slow blinking white	(O)
Blinking white	(O))
Fast blinking white	((O))

((O)) ((O))

Walking:



Current activity

Alternate activity not

Long press



GET STARTED


Wake the knee


The QUATTRO knee ships in Storage **Mode**. The knee will not perform (or wake) until it is plugged into a power supply. To wake the knee: 1. Insert the cable or charged booster battery pack into the charger port. 2. Insert the charger into a power source.

IMPORTANT!

- Do not leave the knee unattended. The battery will discharge when idle.
- To save battery life, place the knee in Storage Mode by pressing and holding both the Change Mode and Wireless buttons until they flash red, white, and blue
- Ensure you have the proper power source to wake the knee before putting the knee into **Storage Mode**.


Connect






3 QUATTRO FULL SETUP


Setup









Calibration



Alignment



Adjust






Controls swing extension resistance.

Adjust Swing Ext. Resistance 50 Stance Ext. Resistance 50 Stair and Ramp Resistance Return 00% 🗷 To decrease resistance + To increase resistance

Controls stance extension resistance.

NOTE

Only adjusted when walking with Stance Flexion.





Provides independent resistance for **stair and ramp decent**.



Provides help encountering an obstacle.



NOTE

If **Sitting Mode** is turned off, it will also disable **Obstacle Assist**.


Adjust

Stair and Ramp

Resistance


When knee flexion is delayed due to high resistance


When knee flexion is rapid due to low resistance



Demonstrate


When the **Flexion Lock** is engaged, it blocks flexion but allows ratcheting up to full extension.






Demonstrate and Adjust

Perform resistance adjustments using a fully discharged battery.



Permissions

Full Setup





Scan for QUATTRO Full setup video



Global Headquarters

6 rue de la Redoute, 21850 Saint-Apollinaire, France +33 (0)3 80 78 42 42 www.proteor.com

US Headquarters

1236 West Southern Ave, Suite 101, Tempe, AZ 85282 855.450.7300 us.proteor.com