$\mathbf{\Lambda} \mathbf{\Lambda} \mathbf{\Lambda} \mathbf{\Lambda} \mathbf{\Lambda} \mathbf{\Lambda}$

Remote Control App Instruction Manual

(iOS Version)

For Users

Product Type: NE-Z41, NE-Z41SH Document Number: 81-SS00128E Date of issue: November 1, 2020



Carefully read the instruction manual prior to use.Keep this instruction manual for future reference.

Nabtesco

Nabtesco Corporation

Introduction

Thank you for purchasing Nabtesco's ALLUX[™].

Matters concerning typical usage such as fitting and walking, maintenance, trouble shooting, and cautionary notes are described in the User's Guide that comes with an ALLUX[™] (hereinafter referred to as the User's Guide).

This Remote Control App Instruction Manual (hereinafter referred to as this manual) describes how to install and use the Remote Control App (hereinafter referred to as this App) in the iOS system environment.

For safe and comfortable use, thoroughly read the User's Guide mentioned above and this manual, sufficiently understand the contents, and strictly observe the safety precautions stated in those documents.

- Nabtesco owns the copyright for this document.
- IOS is a trademark or registered trademark of Cisco in the United States and other countries and is used under license.
- iPhone is a trademark of Apple Inc. in the United States and other countries.
- Apple is a trademark of Apple Inc. in the United States and other countries.
- App Store is a service mark of Apple Inc. registered in the United States and other countries.
- The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG. Inc. and any use of such marks by Nabtesco Corporation is under license.
- QR code is a registered trademark of Denso Wave Incorporated.
- All other company names and product names are trademarks or registered trademarks of their respective companies.

Table of contents

Intr	Introduction ······ 1				
Tab	Table of contents ······ 2				
1	Sup	Supported model and operating environment ······ 3			
2	Inst	all procedures and initial settings······ 4			
3	Saf	e posture······5			
4	Cor	nmunication mode and how to connect Bluetooth ······ 6			
5	ALL	.UX [™] operational modes······· 7			
6	Initi	al settings ······ 9			
7	Мос	de change screen ······ 11			
8	Cor	nnection to ALLUX [™] screen ······12			
9	Acq	uisition of data screen ······13			
10	Ger	neral screen ······14			
11	Abc	out ALLUX [™] screen ······15			
12	Мос	de name screen ······16			
13	3 Error message popup······17				
1	3.1	Connection to ALLUX [™] error ······17			
1	3.2	Password error (3 times) ······17			
1	3.3	Wireless connection error 17			
1	3.4	Wireless communication error 17			
1	3.5	Safe posture error 18			
1	13.6 Hydraulic control error ······				
14	14 Troubleshooting ······19				

1

Supported model and operating environment

● ALLUX[™] (type: NE-Z41)

*ALLUX[™] (type: NE-Z4) is not supported.

The model can be identified by the design of the front link pad.

It can also be identified by the indication on the charging port.





NE-Z41 (Supported type)

NE-Z4 (Non-supported type)



NE-Z41 (Supported type)



NE-Z4 (Non-supported type)

Compatible OS: iPhone running iOS 13 or later

移 Bluetooth°

Precautions on Bluetooth

- Radio waves emitted by a Bluetooth device may affect the operation of electronic devices and other devices. Turn off Bluetooth devices when near priority seats in trains, in areas where flammable gas is generated such as in airplanes near automatic doors and fire alarm devices, as it may cause an accident.
- We do not take any responsibility for the leakage of information when using Bluetooth technology.
- This product does not guarantee wireless connection with all Bluetooth devices. The Bluetooth device to be connected must comply with the Bluetooth standard specified by Bluetooth SIG and must have obtained at least a certification. In addition, even if the device to be connected complies with the Bluetooth standard, phenomena such as inability to connect or different display/operation may occur, depending on the characteristics and specifications of the device.
- Do not disassemble or modify this product as the wireless functionality of this product has been certified to meet technical standards.

Install procedures and initial settings

1. Sign in with your Apple ID.

2

Tap the search icon \bigcirc in the bottom right corner of the "App Store" screen.

2. Type the App name "ALLUX2" into the Search field. Tap the "Search" button on the keyboard.





The following QR code can be used to install.



3. After the search results are displayed, tap the target App as shown below.



- 4. Tap the "GET" button, then tap the "INSTALL" button.
- 5. After the installation is completed, the icon of the App is created on the home screen of the smartphone.
- 6. Tap the icon to start the App.

3 Safe posture

Before changing the operational mode of ALLUX[™] using the Remote Control App, the user needs to take a posture which is safe even if hydraulic resistance changes. This posture is referred to as 'safe posture'. Be sure to understand the following safe postures before using ALLUX[™].

[Safe posture]



- : The ALLUX[™] is fully straighten, stable and will be safe to place your body weight on it.
- : Weight is off of the ALLUXTM, but it may be bent.



■ When taking the safe posture without applying the body weight to ALLUX[™], hold a handrail or sit down.

You may lose your balance and fall over.

[Request for safe posture]

If ALLUX 2[™] is not in the safe posture when changing the operational mode of ALLUX[™], a popup is displayed. Make sure you have the safe posture, and tap "OK" button.



4 Communication mode and how to connect Bluetooth

In order to conserve power, ALLUX[™] is not always in communication mode.

In order to enable the communication mode, you need to perform the following operations.

Once ALLUX[™] communication is established using this App, this state lasts until communication is disconnected.

[Communication mode enabled]

- 1. For 120 seconds after ALLUXTM is slightly flexed and extended
- 2. For 120 seconds after you applies your body weight to ALLUXTM
- 3. For 120 seconds after the charger or the power OFF cap is disconnected from ALLUXTM



It is possible to turn OFF wireless connection when the user gets on a plane, etc. To restore wireless connection from that state, the actions such as the one shown below are required.

- 1. Disconnect the charger or the power OFF cap form ALLUX[™].
- "Apply a load on the heel 4 times intermittently" or "Apply a load on the toe 4 times intermittently"
 *You can switch to either one you like by a method described in page 13.



*Just starting this App does not connect to ALLUX[™]. Tap the Bluetooth icon on the "Mode Change" screen (Refer to page 11) to connect to ALLUX[™].

*Just tapping the home button etc. on the smartphone does not disconnect communication with ALLUX[™] and this App keeps working behind the screen. If you tap the icon of this App again, it starts in the connected state.



Do not turn off the smartphone or force-quit this App while changing a mode with this App. Doing so may cause adjustment values to turn into an unintended state and result in a fall.



■ Even if this App is hidden on the smartphone, the connection with ALLUXTM is maintained and the battery of the smartphone keeps being consumed. If you are concerned about battery consumption, disconnect the smartphone from ALLUXTM or close this App.

ALLUX[™] operational modes

ALLUX[™] has the following five operational modes.

[Normal mode]

5

The normal mode is adjusted for normal walking. Judging various walking situations and normal motions with the sensor, ALLUX[™] automatically adjusts the flexion and extension.

[Flexion angle limit mode]

In flexion angle limit mode, flexion resistance is locked at a designated angle while extension resistance remains free.



[Variable selective flexion lock mode]

ALLUX[™] remembers the angle at which variable selective flexion lock mode is turned on. Flexion resistance is locked when it reaches that angle while extension resistance remains free.



■ When the flexion angle limit mode or variable selective flexion lock mode is NOTICE used, do not apply excessive force to ALLUXTM when locking it. If an excessive impact force is applied to ALLUXTM, it may be damaged.

5 ALLUX[™] operational modes

[Full extension lock mode]

ALLUXTM is locked in a fully extended state.



[Free swing mode]

In free swing mode, ALLUX[™] is kept free (resistance-free state).



Each of these operational modes can be assigned to the buttons in the Remote Control App by the prosthetist using the Adjustment App, and you can change to a mode you want by tapping the corresponding button on the "Mode Change" screen of the Remote Control App (page 11).

The normal mode is always assigned to Button 1 on the Remote Control App.

You can freely assign the five operational modes above to buttons 2 to 5 on the Remote Control App.

Default remote controller configuration:

- Button 2: Flexion Angle Limited mode
- Button 3: Variable Selective Flexion Lock mode
- Button 4: Full Extension Lock mode
- Button 5: Free Swing mode

6

Initial settings

1. Tap the icon of this App to start.



 The "Legal & Regulatory" dialog is displayed. Read it and tap the "OK" button.



3. "Connection to ALLUX[™]" is displayed. Enter the password indicated on the charging port of ALLUX[™]. If you fail in entering the password 3 times, you need to restart this App.





6 Initial settings

4. The company logo is displayed. From the second time, the above screens are skipped and this screen is displayed when you tap the icon of this App.

After the company logo is displayed on screen for a second, this screen is automatically changed to next screen.



5. A warning popup is displayed. Read it and tap the "OK" button.



Mode change screen

"Mode Change" screen is displayed after the warning popup.

•II au '	Ŷ	11:21	- 7 Ö	98% 💻
	ALLUX™ Rem	note Control	۲	÷
	(1)Noi	rmal Mode		
	(0) [u Aurula Liusit		
	(Z)Fiexio	in Angle Limit		
	(3)Variable Sel	ective Flexion	Lock	
	(4)Eull E	stansion Look		
	(5)Fr	ee Swing		
Late	est adjustment d	ate: 2020/10	/2:	
Vibra	ation alarm demo		[
	G Mode Change	Acquis	ition of Da	ta

Bluetooth icon:

Tap this icon to display the "Connection to ALLUXTM" screen (page 12). The icon changes depending on the connection state. When it is in a disconnected state, tap the icon to enable connection.

Disconnected



General icon:

Tap this icon to display the "General" screen (page 14).

Standby mark:



While this App is communicating with ALLUXTM or performing other processing, a standby mark is displayed. While this mark is displayed, all on-screen operations are disabled.

Remote control button:

When you tap one of these buttons, the state of ALLUXTM changes to the operational mode which was assigned by the prosthetist beforehand. When you tap the button, a popup is displayed. Tap the "OK" button.

Screen change tab:

You can switch between the "Mode Change" screen and "Acquisition of Data" screen. Tap on these characters or slide each screen to left or right to switch the screen.

Latest adjustment date:

It shows the date when ALLUXTM was in last adjusted.

Vibration alarm demo button:

ALLUX[™] vibrates in demo.

Battery level:

10% or less

It shows the battery level of ALLUX[™].

10~40%



40~70% 70% or more

7

11 ALLUX[™] Remote Control App Instruction Manual (iOS Version) For Users

Connection to ALLUX[™] screen

No SIM	5:53	84% 🛃			
< Back	Connect ALLUX				
ALLUX:CR09194					
8a22f651-ba51	-b253-6b95-e47aa	a21292b3			
Disconnected					
	•				
	Scan				

8

- On the "Connection to ALLUXTM" screen, scanning for wireless devices automatically starts.
- The devices related to ALLUXTM are listed up. The indicated characters vary based on the serial number of ALLUXTM.

The third line indicates the connection state.

- Disconnected
- Connecting
- Connected
- "ALLUX:Serial No" is displayed. If more than one device is listed up, according to the Serial No. of your ALLUXTM, select the appropriate wireless device.
- If the wireless device for ALLUX[™] is not listed up, the wireless connection of ALLUX[™] may be in sleep mode. Activate the wireless connection referring to page 6. After that, tap the "Cancel button and then tap the "Scan" button displayed in that position to search for wireless devices again.
- Tap the wireless device on the list. If the wireless connection is successfully done, the "Mode Change" screen (page 11) is displayed automatically.

Acquisition of data screen

You can check the state of ALLUX[™] on this screen.

🖬 au 4G 🧳	11:02	@ 🔊 🖉 95% 🗩			
ALLUX™ Remote Control 🛞 🚦					
Current Temperature Total Steps 317 Daily Steps 0 Pedometer 317 Battery	Reset pe	dometer			
Battery ↓ Vibtration for safety lock OFF Reconnection Method Intermittent loading on heel Current ALLUX [™] Mode Normal Mode					
Data acquisition					
€£ Mode Change	Acquis	sition of Data			

• Current Temperature:

You can check the temperature of ALLUX[™]. Repeated yielding motion may cause high temperature. When ALLUX[™] gets hot, it enters high temperature mode and you cannot walk.

Total Steps:

It shows the number of steps you have made up to this point.

Daily Steps:

It shows the number of steps you made on the day.

Pedometer:

When you tap the "Reset pedometer" button, the number of steps becomes 0 once and then it starts to show the number of steps you make from that point.

Battery:

It shows the battery level. (The displayed marks are the same as those shown in page 11 .)

Vibration for safety lock:

This button is used to set whether or not to vibrate the $ALLUX^{TM}$ when the safety lock (page 10 of the User's Guide) is enabled. The default is set to "ON" (vibrate).

Reconnection method:

This button is used to change the method to return wireless connection to ON without using the charger or the power OFF cap when wireless connection was turned OFF to get on a plane, etc. Refer to page 6.

● Current ALLUX[™] Mode:

Shows the current walking mode. Refer to page 7.

Data acquisition button:

When you tap this button, information such as the number of steps is updated.

9

10 General screen

When you tap the General icon i on the "Mode Change" screen or the "Acquisition of Data" screen, the screen displays the "General" screen.

No SIM 奈	14:17	100% 🗩	● About ALLUX [™] :
K Back	General		"About ALLUX [™] " screen (page 15) is displayed.
About ALLUX ^T	м		
Change the name of mode			Change the name of mode:
Airplane mode	9		"Mode Name" screen (page 16) is displayed.
Reboot			Airplane mode:
Instruction Manual			A popup is displayed. Tap the "OK" button to turn OFF
instruction wa			ALLUX [™] wireless connection.
Legal & Regula	atory		
			Reboot:
			When you tap this button, a popup is displayed. Tap the
			"OK" button to reboot ALLUX™.
			* As the communication is disconnected, you need to
			enable connection again.
			(The same action as removing and inserting the power
			OFF cap.)

Instruction Manual:

Download the instruction manual from jumped link.

Legal & Regulatory:

The "Legal & Regulatory" dialog (page 9) is displayed.

11 About ALLUX[™] screen

No SIM	18:19	100% 🚧
〈 General	About ALLUX™	
App Versior	ı	
0.4.0		
ALLUX™ fir	mware version	
50.36/07.32		
Serial No.		
CR09198		

• App Version:

The version of this App is displayed.

● ALLUX[™] firmware version:

The firmware version of ALLUX[™] is displayed.

Serial No:

The serial number of the ALLUXTM is displayed.

12 Mode name screen

ALLUX[™] allows to freely assign the operational modes described in page 8 to the buttons on the Remote Control App. ALLUX[™] also allows to change the button names indicated on the "Mode Change" screen. Be sure to check the assignment with the prosthetist and change the button names according to the assignment.

It is convenient to name the buttons according to the adjustment values, for example, 'Normal mode (for a shoe with a high heel)' or 'Flection Angle Limited mode (50 deg.)'.

If the prosthetist changes the mode assignment, the mode names return to the defaults.

No SIM 奈	14:19	100% 🔲			
く Back	Change the name of mode				
The na	me of ALLUX™ Mode 1				
(1)Normal Mode					
The na	me of ALLUX™ Mode 2				
(2)Flexion Angle Limit					
The na	me of ALLUX™ Mode 3				
(3) Variable Selective Flexion Lock					
The na	me of ALLUX™ Mode 4				
(4)Full Extension Lock					
The na	me of ALLUX™ Mode 5				
(5)Fre	e Swing				

- 1. Tap the operational mode to change the name.
- 2. A keyboard is displayed on the screen.
- 3. Enter a new name.
- 4. Tap " \checkmark " to complete the entry.
- 5. Once return to "Mode Name" screen, the name is reflected to this App.

13 **Error message popup**

If an error occurs during an operation, a popup is displayed. Please follow the instructions in the popup.

13.1 Connection to ALLUX[™] error

Error Password is not correct. Please enter password again.

OK

13.2 Password error (3 times)

Error Password Fail 3 times. The application ends when the "OK" button is pressed.

OK

13.3 Wireless connection error

Error unable to connect ALLUX.Re-establish wireless connection.

OK

13.4 Wireless communication error

unable to connect ALLUX.Re-establish wireless connection.

screen. Enter the password indicated on the charging port again.

This error occurs when the wrong password

was input on the "Connection to ALLUX™"

This error occurs if you fail in entering the password 3 times. And then this App closes at once. When you start up this App again, you can enter the password again.

This error occurs when wireless connection between ALLUX[™] and Bluetooth on smartphone is failed. Try to turn ON the wireless connection of ALLUX[™] referring to page 6.

This error occurs when communication between ALLUX[™] and App on smartphone is failed. Enable wireless connection again referring to page 11.





13.5 Safe posture error



If the user does not take a safe posture, ALLUX[™] cannot change the settings. Assume a safe posture referring to page 5.

13.6 Hydraulic control error

ALLUX[™] Remote Control

A warning requests you to refrain from use of ALLUX™.Contact the prosthetist.

OK

Because hydraulic control may be out of order, the control of ALLUX[™] is stopped. Contact the prosthetist to have maintenance service.

14 Troubleshooting

Problem	Check item	Remedy
The Remote	Check that the operating system version is	Update the operating system to
Control App cannot	appropriate.	iOS 13 or later.
be installed.	Check that the hard disk of the smartphone	Increase the free space on the
	etc. has a required free space.	hard disk.
ALLUX [™] cannot	Check that ALLUX [™] is recognized on the	Select ALLUX [™] on the
be connected.	"Connection to ALLUX™" screen (page 12).	"Connection to ALLUX™" screen.
	Check that ALLUX [™] communication is not	ALLUX [™] cannot be connected
	connected with multiple devices.	with multiple devices. If the
		prosthetist is using the Adjustment
		App, ask the prosthetist to
		disconnect the communication.
	Check that Bluetooth is ON on the	Turn ON Bluetooth on the
	smartphone.	smartphone.
Wireless	Check that the toe or heel setting is correct	Check the setting with this App or
connection cannot	or the way of applying a load is correct.	the way of applying a load again
be restored even if		referring to page 6. If the wireless
a load is applied on		connection still cannot be restored,
the heel or the toe		remove and insert the battery
4 times		charger or the power OFF cap for
intermittently.		restoration.
ALLUX [™] is not	Check that the ALLUX [™] wireless	Turn ON wireless connection
indicated on the	connection is ON.	referring to page 6.
"Connection to	Check that battery for ALLUX [™] has been	Charge the battery for ALLUX [™] .
ALLUX [™] " screen.	charged.	
	Check that multiple Apps are not working at the same time	Close unnecessary Apps.
	Check that the Bluetooth function is ON on	Turn ON the Bluetooth function
	the smartphone.	
Communication	Check that the battery capacity for ALLUX $^{\rm TM}$	Charge the battery for ALLUX [™] or
between ALLUX™	or smartphone is low battery status.	smart phone.
and App is easily	Check ALLUX™ is used under the specific	Avoid using the device in an
disconnected.	wireless condition such as beside railway,	environment where trains or
	highway, TV tower, airport, in exhibition and	vehicles frequently come and go,
	hospital.	or in an environment where there
		are multiple wireless connections.
	Check if there are huge shields against	Remove shields that block radio
	radio wave around ALLUX™ user.	waves.

$\mathbf{\Lambda} \mathbf{Z} \mathbf{Z} \mathbf{Z} \mathbf{X}^{\mathsf{T}}$

Nabtesco Corporation

Manufacturer

Nabtesco Corporation

Accessibility Innovations Company Assistive Products Department

35, Uozakihama-machi Higashinada-ku Kobe, Japan 658-0024 TEL: +81-78-413-2724 FAX: +81-78-413-2725 http://welfare.nabtesco.com

Contact

Authorized representative for EU countries

ORTHO-REHA Neuhof GmbH

Registered Address: Gundelfinger Straße 6 90451 Nürnberg, GERMANY

TEL: +49.911.643.3940 FAX: +49.911.660.4124

Please contact us if you find any page missing or disordered.

Nabtesco

Nabtesco Corporation